



# MC62

Mobile Computer

## Accessories Guide

### Standard

#### Adapters



PWR-C62-5V2A-CN



PWR-C62-5V2A-EU



PWR-C62-5V2A-US

Adapter (CN/EU/US), I/P: 100-240V, O/P: 5V2A, use with DC-BK-TypeC cable

#### Adapters



PWR-18W-CN



PWR-18W-EU



PWR-18W-US

Adapter (CN/EU/US), I/P: 100-240V, O/P: 5V2A, use with DC-BK-TypeC cable

#### USB Cable



DC-BK-TypeC  
1.0 meter Type-C cable.

#### Hand Strap



RB-C62-HS  
Hand strap

#### Battery



BTRY-C62-50MA  
Main battery, 5000mAh Li-on battery,  
Limited charge voltage: 4.45V.

### Optional

#### Charging Cradles



CRD-C62-RBC  
Charging cradle for device and battery, w/DC, use with 12V2A adapter.



CRD-C62-MBC  
Charging cradle for main battery, up to 4 slots, use with 12V3A adapter.

#### Adapters



DCPWR-12V2A-CN/EU/US  
Adapter(CN/EU/US), I/P:100-240V, Pistol O/P:12V2A, DC.



DCPWR-12V3A-CN/EU/US  
Adapter(CN/EU/US), I/P:100-240V, Pistol O/P:12V3A, DC.

#### Rugged Rubber Boot




RB-C62-RR  
Rugged Rubber Boot only,omni-directional protected.  
RB-C62-RR does not support charging cradle.

#### Pistol Grip



TRG-C62-PG  
MC62 pistol grip without battery, barcode scanning like pressing the trigger.

#### Screen Protector



SP-C62  
Tempered glass screen protectory.