

SR160

UHF RFID Scanner

Accessories Guide

Standard

Adapters



PWR-SR160-5V2A-CN



PWR-SR160-5V2A-EU



PWR-SR160-5V2A-UK



PWR-SR160-5V2A-US

Adapter (CN/EU/UK/US), I/P: 100-240V, O/P: 5V2A, use with DC-SR160-TypeC cable.
Standard for SR160(Bluetooth version)

Type-C cable



DC-SR160-TypeC
1.0 meter Type-C cable. Standard for SR160(Bluetooth version)

RJ45 to USB cable



CBL-RJ45-USB-2M
2.0 meter RJ45 to USB cable. Standard for SR160(USB version)

Optional

Charging Cradle



CRD-SR160-SCC
SR160(Bluetooth version) charging cradle(General configuration), charge one SR160 Bluetooth version device, use with DC-SR160-TypeC cable

Desktop Stand



SR160-DS
SR160 desktop stand